

INSTRUKCE



Model: P130

Vítejte:

Vítejte u tohoto produktu. Před použitím produktu si pečlivě přečtěte pokyny. Tento produkt je praktickým zařízením se sledováním videa v reálném čase, nahráváním videa, snímáním obrazu a dalšími funkcemi. Je vhodný pro úzké prostory a ty, které nelze pozorovat zrakem, jako jsou: údržba automobilů, kontrola/údržba kanalizace atd.

Funkce:


- 1,4,3palcový plně barevný HD displej pro sledování v reálném čase.
 2. Rozlišení kamery je až 1080P, dobré pro snímání obrazu, nahrávání videa.
 3. Více čoček, volitelná délka čáry
 4. Pro dosažení funkce ukládání souborů lze nainstalovat kartu TF.
- Vysoce citlivá vodotěsná kamera o průměru 5,8 mm s čistou kvalitou obrazu pro různá pracovní prostředí.
6. Speciální technologie s ohniskovou vzdáleností. 5 cm-500 cm pro přední kameru a 3 cm-500 cm pro boční kameru.
 7. Nastavitelná LED světla pro snadné použití v tmavém prostředí.
 - 8.P68 vodotěsný.



Fotoaparát



Lze fotit



HD



Úložiště TF karty



Umí nahrávat videa



Otočný



Voděodolný




Led světla

Seznam balení:

1. endoskop
2. Uživatelská příručka
3. Nabíjecí kabel
4. Příslušenství-háčky, magnety, boční zrcátko

Představení struktury:



1. Spínač pomocných světel

2. Pomocná lampa

3. Duální fotoaparát

4. Nahoru/Otočit doleva

5. Dolů

6. Menu

7. Zpět

8. Potvrďte ok

9. Take Photos/Videos

10. Upravte světla

11. Zapnutí/vypnutí

Představení funkce:

1. Slot pro kartu Micro TF: podporuje až 128 GB kartu Micro TF. Podporuje pouze karty TF s formátem FAT32 třídy 10 nebo vyšší (karta TF, která není ve formátu FAT32, bude po vložení do zařízení automaticky naformátována na formát FAT32).

2. Micro sedadlo: napájení 5V.

3. Tlačítko Start: Stisknutím a podržením po dobu 3 sekund spustíte stroj a zobrazí se obrazovka v reálném čase. Stisknutím a podržením po dobu 3 sekund se vypne.

4. Tlačítko Photo: krátkým stisknutím pořídíte fotografii, dlouhým stisknutím spustíte video a poté jedním krátkým stisknutím zastavíte.

5. Tlačítko Menu: Krátkým stisknutím vstoupíte na stránku nabídky:

PhotoVideo, Rozlišení Jazyk/Jas/Otočit/DateTag/Nastavení času/Formát

Resetovat systém/Mezerník/Verze V rozhraní nabídky krátce stiskněte „nabídku“.

tlačítko pro vstup do rozhraní obrázku.

6. Tlačítko OK: krátkým stisknutím potvrďte.


7. Tlačítko Nahoru: V rozhraní nabídky krátkým stisknutím vyberte položku nahoru. Když jste v obrazovém rozhraní,

8. Tlačítko Dolů: V rozhraní nabídky krátkým stisknutím vyberte směrem dolů. Když jste v obrazovém rozhraní,

Použijte kroky:

(1) Základní operace

1. Vložte kartu Micro TF do slotu karty Micro TF; jemně stiskněte, dokud se karta nezamkne (Poznámka: Chcete-li nahrávat a ukládat obrázky a videa, musíte vložit kartu Micro TF třídy 10)



2. Po zapnutí produktu můžete vidět obraz v reálném čase v režimu duální čočky.

3. Krátkým stisknutím pořídíte snímek, dlouhým stisknutím nahrajete video a dalším stisknutím nahrávání zastavíte.

Technické parametry:

Modelové číslo	P130
Zobrazit	4,3palcový barevný IPS HD displej
rozlišení fotoaparátu	1920*1080
Horizontální perspektiva	70°
Jazyk	Angličtina, čínština, japonština, francouzština, němčina, čeština, portugalština, polština, holandština, turečtina
Délka čáry	2m/5m/10m volitelně
Ohnisková vzdálenost	5CM-500CM
Voděodolný	IP68 (pouze pro objektiv)
Průměr kamery	8mm/5,5mm/3,9mm/14mm/11mm volitelně

Odstraňování problémů:

Problémy	Řešení
Zařízení nelze zapnout	1. Je baterie nabitá? 2. Je napájení úspěšně připojeno?
Čtení TF karty se nezdařilo	1. Je formát paměťové karty správný? (Toto zařízení podporuje pouze formát souborů FAT32). 2. znovu vložte kartu.
Zařízení se zhroutlí	Pro resetování restartujte.
Šmouhy nebo šmouhy na obrazovce	Opatrně očistěte obrazovku měkkým hadříkem.
Nelze nabíjet	Zapojte do stejnosměrného vstupního portu zařízení, ujistěte se, že je zásuvka napájena a není vadná.

Informace FCC:

Toto zařízení vyhovuje části 15 pravidel FCC. Splňte následující dvě podmínky:

- (1) Toto zařízení nebude způsobovat škodlivé rušení.
- (2) Toto zařízení musí akceptovat jakékoli přijaté rušení, včetně rušení, které může způsobit neočekávanou činnost. Změny nebo úpravy, které nejsou výslovně schváleny stranou odpovědnou za shodu, mohou zrušit oprávnění uživatele provozovat zařízení.

Ochrana životního prostředí EU:

Odpadní elektrické výrobky by neměly být likvidovány společně s domovním odpadem. Doporučení k recyklaci vám poskytne místní úřad nebo prodejce.

Distributor

Sunnysoft s.r.o.
Kovanecká 2390/1a
190 00 Praha 9
Česká republika
www.sunnysoft.cz

CEFCIR

Vyrobeno v Číně

Jakékoli drobné změny v obrázcích obsažených v uživatelské příručce nepodléhají žádnému dalšímu upozornění.

INSTRUCTIONS



Model : P130

Welcome:

Welcome to this product. Please read the instructions carefully before using the product. This product is a practical equipment with real-time video viewing, video recording, image capture and other functions. It is suitable for narrow areas and those that cannot be observed by sight, such as: car maintenance, sewer inspection/maintenance, etc.

Features:

1. 4.3-inch full color HD screen for real-time viewing.
2. The resolution of the camera are up to 1080P, good for image capture, video recording.
3. Multiple lenses, selectable line length
4. TF card can be installed to achieve file storage function.
5. 8mm diameter high-sensitivity waterproof camera with clear picture quality for different working environments.
6. Special technology with a focal length. 5 cm-500cm for the front camera and 3cm-500cm for the side camera.
7. Adjustable LED lights for easily using in dark environments.
8. P68 waterproof.



camera



Can take photos



HD



TF Card storage



Can record videos



Rotatable



Waterproof




LED lights

Packing list:

1. endoscope
2. User's Guide
3. Charging cable
4. Accessories- hooks, magnets, side mirror

Structure introduction:



- 1. Auxiliary lamp switch
- 2. Auxiliary lamp
- 3. Dual camera
- 4. Up/Rotate Left
- 5. Down
- 6. Menu

- 7. Back
- 8. Confirm ok
- 9. Take Photos/Videos
- 10. Adjust the Lights
- 11. Power on/off

Function introduction:

- 1. Micro TF card slot: supports up to 128GB Micro TF card Only supports TF cards with class 10 or higher FAT32 format (TF card which not in FAT32 format, will be automatically formatted into FAT32 format after being inserted into the device).
- 2. Micro seat: 5V power supply.
- 3. Start button: Press and hold for 3 seconds to start the machine, displaying a real-time screen. Press and hold for 3 seconds to shut down
- 4. Photo button: short press to take a photo, long press the start the video, then short press once to stop.
- 5. Menu button: Short press to enter the menu page: PhotoVideo, Resolution Language / Brightness / Rotate / Date Tag / Time Setting / Format / Reset system / Space / Version In the menu interface, short press the "menu".

button to enter the image interface.

6. OK button: short press to confirm.


7. Up button: When in the menu interface, short press to select upwards. When in the image interface,

8. Down button: When in the menu interface, short press to select downwards. When in the image interface,

Use steps:

(1) Basic operation

1. Insert the Micro TF card into the Micro TF card slot; press gently until the card is locked (Note: Class 10 Micro TF card must be inserted to record and store pictures and videos) .



2. After the product is turned on, you can see the real-time image in dual lens mode.

3. Short press to take a picture, long press to record a video, and then press again to stop recording.

Technical Parameters:

Model number	P130
Display	4.3-inch color IPS HD display
camera resolution	1920*1080
Horizontal perspecti	70°
Language	English, Chinese, Japanese, French, German, Czech, Portuguese, Polish, Dutch, Turkish
Line length	2m/5m/10m optional
Focal length	5CM—500CM
Waterproof	IP68 (only for lens)
Camera diameter	8mm/ 5. 5mm/ 3. 9mm/ 14mm/ 11mm optional

Troubleshooting:

Problems	Solutions
Device cannot be turned on	1.Is the battery charged? 2.Is the power connected successfully?
TF card reading failed	1.Is the format of the memory card correctly? (This device only supports FAT32 file format). 2.reinsert the card.
Device crashes	Reboot to reset.
Smudges or smudges on the screen	Carefully clean the screen with a soft cloth.
Can't charge	Plug into the DC input port of the device, make sure the outlet is powered and not faulty.

FCC information:

This device complies with Part 15 of the FCC Rules. Meet the following two conditions:

- (1) This device will not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause unexpected operation. Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate the equipment.

EU environmental protection:

Waste electrical products should not be disposed of together with household garbage. Please consult your local government or retailer for recycling recommendations.



Made in China

Any minor changes in the figures contained in the user manual are subject to no further notice.