



Představení funkce

A. Čas a datum:

Zobrazuje aktuální čas a datum.

Poznámka: Carplay může po připojení automaticky synchronizovat čas a datum v telefonu. Android auto potřebuje vstoupit do Nastavení, aby bylo možné ručně zkalibrovat čas a datum

B. Tlačítko Domů:



Klepnutím na toto tlačítko vstoupíte do hlavního rozhraní.

C. Tlačítko jasu:



Kliknutím upravíte jas obrazovky



Zapněte automatické nastavení jasu, jas obrazovky stroje se automaticky upraví podle jasu okolního prostředí



Vypněte automatické nastavení jasu. Jas obrazovky můžete upravit posunutím bílého ukazatele průběhu uprostřed.

D. Tlačítko hlasitosti:

Klepnutím upravte hlasitost

Po výběru jiného režimu se ikona hlasitosti změní na odpovídající ikonu

Například: BT NA Reproduktor FM

E. Přepínač obrazovky



Kliknutím na obrazovku na hlavní stránce vypnete podsvícení obrazovky, dalším kliknutím kamkoli na obrazovku zapnete vypínač obrazovky nebo stisknutím tlačítka zapnutí na stroji zapnete nebo vypnete podsvícení obrazovky.




Klepnutím na toto tlačítko se vrátíte na předchozí obrazovku

F. DVR



Jak je znázorněno na obrázku výše, na hlavní stránce se nezobrazí obraz z kamery, pro zobrazení obrazu z kamery musíte kliknout na tlačítko Dvr. Po vložení karty systém automaticky přejde do režimu videa a po záznamu budou malé červené tečky na tlačítku [Sledování jízdy] blikat.



	Zapněte nebo vypněte nahrávání zvuku.
	Uzamkněte video na několik minut a data nebudou smazána.
	Spusťte nahrávání a znovu klikněte na Zavřít nahrávání.
	Zobrazit přehrávané video.
	Kliknutím sem přepnete do rozhraní nastavení.


G. CarPlay



Jak je znázorněno na obrázku výše, klikněte na tlačítko [Apple CarPlay pro vstup do výběru Apple CarPlay a Android Auto, klikněte na možnost [Správa Bluetooth) v rozhraní a připojte se k Bluetooth s mobilním telefonem, můžete otevřít aplikaci. Když je stroj zapnutý, pokusí se automaticky připojit k naposledy připojenému telefonu.

(Chcete-li se odpojit, vypněte tlačítko Wi-Fi, možnost Apple Carplay podporuje pouze telefony iPhone, pro

odpojení vypněte tlačítko Wi-Fi telefonu)




V rozhraní nastavení



Klikněte na rozšířenou obrazovku

zobrazení pro výběr celé obrazovky, vlevo a vpravo

(Režim poloviční obrazovky)



(Režim celé obrazovky)



Poznámka: V rozevírací nabídce mobilního telefonu musíte nejprve klepnutím vypnout

Bluetooth a poté klepnutím na tlačítko Vypnout WiFi se odpojit. Stačí vypnout pouze tlačítko WiFi a auto

se bude nadále pokoušet znovu připojit



H. Android Auto



Nejprve zapněte Wi-Fi a Bluetooth mobilního telefonu, poté vyberte možnost [Android Auto], klikněte na možnost rozhraní [BT Manage], připojte Bluetooth k telefonu, můžete otevřít aplikaci. (Tlačítko vypnout Wi-Fi pro odpojení)


Po výměně mobilního telefonu budou vymazána data připojení předchozího mobilního telefonu.

Nejprve zapněte Wi-Fi a Bluetooth mobilního telefonu a poté vyberte možnost [Android Auto], klikněte na možnost [BT Manage] rozhraní, připojte Bluetooth k telefonu, můžete otevřít aplikaci.

(Chcete-li se odpojit, vypněte tlačítko Wi-Fi)



Po výměně mobilního telefonu budou vymazána data připojení předchozího mobilního telefonu.




V rozhraní nastavení

zobrazení pro výběr celé obrazovky, vlevo a vpravo


(Režim poloviční obrazovky)



(Režim celé obrazovky)



I. Přehrávání



Jak je znázorněno výše, kliknutím na tlačítko [Přehrávání] vstoupíte do rozhraní přehrávání videa.



Kliknutím na tlačítko [Smazat] materiál odstraníte.



Kliknutím přehrajete nebo pozastavíte video.



Klepnutím nebo přetažením ukazatele průběhu můžete video soubor rychle převinout dopředu nebo dozadu



Kliknutím přepnete na další video



Klikněte na zamknout nebo odemknout video soubor, můžete vybrat aktuální soubor nebo všechny soubory pro zamknutí nebo odemknutí souboru.



Kliknutím na Delete video file potvrďte smazání video souboru, můžete si vybrat smazání aktuálního souboru nebo všech souborů.

J. Zvukový výstup



Jak je znázorněno na obrázku, kliknutím na tlačítko [Audio Output] vstoupíte do rozhraní výběru zvukového výstupu.

Auto audio výstup: Klikněte pro vstup, lze vybrat čtyři možnosti (reproduktor, Carplay/Auto, FM, AUX).

1. BT

[BT] : Vyberte tento režim a poté se připojte k [Apple CarPlay] nebo [Android Auto], abyste přenesli obrazovku, můžete použít Bluetooth telefonu k přímému připojení k Bluetooth původnímu vozu. Po úspěšném připojení. všechny zvuky ze zařízení budou přenášeny do originálních reproduktorů auta přes Bluetooth.

Po výběru tohoto režimu se ikona hlasitosti změní na ikonu Bluetooth přenosu

[BT] Vyberte tento režim Klepnutím na tlačítko OK potvrdíte přepnutí z jiného režimu výstupu zvuku Výstup BT nebo přepnutí z režimu výstupu BT do jiného režimu výstupu zvuku při připojení

[Apple CarPlay] nebo **[Android Auto]** budou před opětovným připojením krátce odpojeny a na tomto zařízení nelze upravit hlasitost, takže hlasitost je nutné upravit na původním voze.



Požadavky:

1. Auto podporuje Bluetooth.
2. Podporovány jsou pouze telefony iPhone a Android Auto Výhody funkce BT: pro Carplay:

V tomto režimu uživatel nemusí pokaždé po nastoupení do auta nastavovat výstupní kanál zvuku na mobilním telefonu na původní zařízení Bluetooth ve vozidle. Zvuk je přímo

odeslané z mobilního telefonu do Bluetooth původního vozu a vy si můžete vychutnat kvalitu zvuku původního vozu.

Kroky použití BT pro Carplay:

- ① Vyberte režim [BT pro carplay/Auto] v [Audio Channel] na chytré obrazovce.
- (2) Připojte se pomocí telefonu k režimu Apple Carplay nebo Android Auto.
- ③ Propojte Bluetooth původního vozu s Bluetooth mobilního telefonu.

Po dokončení výše uvedených 3 kroků lze zvuk nebo data hovoru přehrávat z originálního autorádia.

Další pokyny:


Pokud po dokončení výše uvedených tří kroků na telefonu Android stále hraje hudba z telefonu, musíte otevřít stavový řádek telefonu a přepnout výstupní kanál zvuku

k přehrávání Bluetooth v autě, jak je znázorněno na obrázku 1 a obrázku 2:

Případně v nastavení Bluetooth v telefonu vyhledejte zařízení Bluetooth, které bylo dříve připojeno k

Android Auto: T93-XXXXXX (ne originální zařízení Bluetooth do auta), klikněte na tlačítko nastavení na pravé straně Bluetooth a zavřete [Zvuk médií]


tlačítko, jak je znázorněno na obrázcích 3 a 4:



2. AUX IN

[AUX IN]: Po výběru tohoto režimu bude ve výchozím nastavení zapnut režim výstupu AUX.

Pomocí kabelu zdroje zvuku AUX připojte chytrou obrazovku k původnímu vozidlu. Po připojení je úspěšné, všechny zvuky zařízení se přenesou do původního vozu reproduktory přes kabel zdroje zvuku AUX pro přehrávání.



Po zvolení tohoto režimu se ikona hlasitosti změní na ikonu AUX výstupu [OK] a hlasitost nelze na tomto zařízení upravit, proto je nutné hlasitost upravit na původním voze.

3. Reprodukter

【reprodukter】 Vybte tento režim a potvrďte kliknutím na tlačítko [OK].



【Reprodukter】 : Zvuk bude přehráván z reproduktoru chytré obrazovky.

4. FM vysílač

Po výběru tohoto režimu klikněte na tlačítko [OK] pro potvrzení režimu vysílání FM ve výchozím nastavení zapnuto. Pokud je například vysílací pásmo FM zařízení naladěno na FM 93,3 MHz (lze použít jakýkoli neobsazený kanál), naladi autorádio také své přijímací pásmo na stejné FM 93,3 Hz. Po úspěšném připojení budou všechny zvuky zařízení přenášeny do originálních reproduktorů automobilu prostřednictvím FM přenosu.

Po výběru tohoto režimu se ikona hlasitosti změní na ikonu vysílání FM [FM] a hlasitost nelze na tomto zařízení upravit, takže hlasitost je nutné upravit na původním voze.


(Nepoužívání originálního napájecího kabelu může mít za následek zhoršení signálu vysílání FM nebo ztrátu funkce.)



K. Apple Airplay

Apple AirPlay může přenášet videa, zvuk a obrázky z iPhone do zařízení v autě, kde je můžete přehrávat a sledovat. Od bezdrátového Bluetooth se zásadně liší. Nosičem přenosu je WIFI.

Potřebujete připojení iPhone k wifi



Vybte chytrou obrazovku v zrcadle obrazovky v ovládacím centru iPhone

Poznámka: Podporujte pouze mobilní telefony iPhone.



L. Android Cast

Dokáže realizovat zrcadlovou projekci mobilního telefonu a automobilu.

Ke stažení, instalaci a spuštění aplikace „Dylink“ je potřeba naskenovat kód mobilním telefonem.



Poznámka: Podporuje pouze telefony Android

K. Nastavení



Podrobnosti nabídky nastavení		
Funkce menu	IKONY nabídky	Provozní funkce
Projekce na plátno		Můžete si vybrat zobrazení levé, pravé a celé projekční plochy. Při přepínání režimu projekce se Carplay nebo Android Auto krátce odpojí a poté znovu připojí.
Rezoluce		V rozhraní nastavení nabídky si uživatelé mohou vybrat video 1440P (2K) nebo 2160P (4K); Toto ustanovení Platí pouze pro přední fotoaparát, nikoli pro zadní fotoaparát
Nahrávání ve smyčce		V rozhraní nastavení nabídky si uživatelé mohou sami zvolit dobu úpravy filmů, která podporuje 1 minutu, 2 minuty, tři režimy v minutách
Mikrofon		V rozhraní nastavení nabídky použijte toto tlačítko pro zapnutí nebo vypnutí funkce nahrávání
G-senzor		Vestavěný kolizní senzor (G-senzor), pokud dojde k vážné kolizi, rekordér nehodu uzamkne. Současně se ikona ve spodní části displeje automaticky změní na uzamknutou; Be locked in Je uložen jako speciální soubor, který nebude přepsán smyčka. Senzor gravitace (G-senzor) podporuje vysoké, střední, nízké; zavřít čtyři nastavení citlivosti, podle skutečné Musíte změnit Nastavení sami v Nabídka nastavení
Společné obrazovky		V rozhraní nastavení nabídky si uživatel může vybrat funkci spánku obrazovky, stroj podporuje zavření spánku 30 sekund, Čtyři režimy jsou 60 sekund a 180 sekund
Zadní video zrcátko		V nabídce pro nastavení rozhraní stroje může uživatel zvolit otevření a zavření funkce zrcadlení
Jazyk		V rozhraní nastavení nabídky si uživatelé mohou vybrat jazyk podle svých potřeb, podporovat více jazyky: angličtina/简体中文/繁体中文/日本語/한국어 / ruština / francouzština / španělština / polština / arabština

Datum/čas		V rozhraní pro nastavení nabídky může uživatel kliknout na datumové hodiny pro nastavení, upravit datum a čas a nakonec stisknout tlačítko „OK“ v pravém dolním rohu pro ukončení. Poznámka: Aby bylo možné efektivně zaznamenat datum a čas shromažďování důkazů o nehodě související s bezpečností řízení, prosím použijte tento stroj před Okamžitě nastavte správný čas
APP		Naskenujte aplikaci pro stahování kódu pro zobrazení a stahování video souborů Viz pokyny níže. 1
Formátování TF karty		V rozhraní nastavení nabídky klikněte na tlačítko operace, formát karty TF, zobrazí se vyskakovací okno, bod Tlačítko "OK" zformátuje akci
Tovární Reset		V rozhraní nabídky Nastavení klikněte na provozní tlačítko, objeví se vyskakovací okno s výzvou „Obnovit tovární nastavení Odstraní použití a vrátí všechna nastavení na tovární nastavení. stav“, kliknutím na tlačítko "OK" se vrátíte zpět. Návrat k továrnímu nastavení klikněte
Zvuk při zapnutí		na (Zapnout zvuk) Pro zadání nastavení: můžete zvolte zavřít nebo zapnout. Při volbě off se zvukový efekt na zdroji vypne
O		Tato položka zobrazuje hlavně informace o verzi firmwaru, včetně času softwaru a dalších informací, a uživatelé ji nemohou nastavit.

1.APP

Jak je znázorněno na obrázku výše, nejprve naskenujte QR kód a stáhněte si odpovídající APP.

Po stažení otevřete APP a postupujte podle pokynů APP pro připojení k WiFi zařízení stroj. Název WiFi: T93-XXXXXX, heslo zobrazené na zařízení.

(Chcete-li se odpojit, vypněte klíč WiFi mobilního telefonu)



Poté, co mobilní telefon stáhne APP, zapněte funkci WIFI mobilního telefonu, připojte se k názvu hotspotu zobrazenému na straně zařízení, zadejte heslo 12345678 a počkejte, až se mobilní telefon a zařízení úspěšně spojí. Otevřete APP [Viidure] na mobilní straně a klikněte na pozici kamery níže. Mobilní telefon zobrazí na stroji obrazovku náhledu fotoaparátu a zařízení zavře jakoukoli operaci a zobrazí pouze obrazovku náhledu fotoaparátu.

2. Zapojení a instalace zadní vytahovací kamery



Způsob instalace zadní kamery se liší podle polohy instalace. Před výběrem vhodného způsobu instalace potvrďte polohu instalace.

Po potvrzení montážní polohy očistěte povrch montážní pozice od oleje a prachu. Pokud není lepení pevné, může zadní kamera během jízdy spadnout.

Pro lepší výsledky se doporučuje instalovat zadní kameru mimo vůz. Tento fotoaparát je voděodolný, takže se o něj nemusíte bát.


Pro bezpečnou jízdu vedte kabely tak, aby nebránily v jízdě.

Poté, co vozidlo zařadí zpátečku, obraz rekordéru se automaticky přepne na zadní kameru a zobrazí pomocnou čáru zpátečky. Po opuštění zpátečky se zařízení vrátí do normálního stavu zobrazení.

Přestože je na snímku zadní kamery zobrazena vodící čára snímání vzdálenosti za vozidlem, nelze zobrazit všechny nebezpečné překážky. Nedívejte se jen na obraz couvání na obrazovce a vizuálně zkontrolujte zadní část.

Kalibrace obrácené linie

Zaparkujte vůz uprostřed parkovacího místa poté, co je vozidlo připojeno ke zpátečce, když je obrázek náhledu zadní kamery mimo pomocnou čáru zpátečky, ručně přetáhněte čtyři rohy pomocné čáry zpátečky, upravte polohu couvacího vozu, pomocné čáry zpátečky, dole a vlevo a vpravo tak, aby zpětná pomocná čára a parkovací čára jsou rovné se zemí



Distributor
 Sunnysoft s.r.o.
 Kovanecká 2390/1a
 190 00 Praha 9
 Česká republika
www.sunnysoft.cz

L. Odstraňování problémů

Položka	Zkusme to	Řešení
1	Nelze spustit DVR podporuje použití 12-24V v autě	1) Zkontrolujte, zda není stejnosměrná hlava napájecího kabelu zapalovače poškozená nebo stárnoucí. 2) Zkontrolujte, zda není odpojená nebo spálená pojistka síťové zástrčky.
2	Žádný dotykový jev	1) Dotyk je neplatný během zapínání, před použitím počkejte na normální zapnutí. 2) Zkontrolujte, zda není dotyk poškozen, nedotýkejte se jej obrazovka s ostrými předměty, lze ji snadno poškrábat a poškodit.
3	Zadní kamera nemá žádný obrázek	1) Předtím si kupte odpovídající zadní kameru od výrobce dá se to použít. 2) Zda je rozhraní AVIN zasunuto dolů. 3) Zkontrolujte, zda se formát fotoaparátu shoduje
4	Carplay nemůže připojit	1) První připojení trvá o něco déle. 2) Carplay podporuje pouze iPhone. 3) Zkontrolujte, zda jsou funkce WiFi a Bluetooth v mobilu telefony jsou normální. 4) Vstupte do Nastavení-Obecné-Carplay vozidlo, smažte všechny záznamy a znovu se připojte. 5) Restartujte iPhone a znovu jej připojte.
5	Android Auto nelze připojit	1) Podporovány jsou pouze telefony Android. 2) Aktualizujte Auto a související aplikace na mobilních telefonech na nejnovější verzi. 3) Zkontrolujte, zda jsou funkce WiFi a Bluetooth v mobilu telefony jsou normální. 4) Restartujte telefon Android a znovu jej připojte.

Připomenutí: Ujistěte se, že mezi mobilním telefonem a zařízením není žádná překážka zařízení a komunikace signálu Wi-Fi / Bluetooth je hladká, jinak produkt funkce nelze plynule používat.



Function introduction

A. Time and Date:

Displays the current time and date

Note: Carplay can automatically synchronize the time and date on the phone after connecting, Android auto needs to enter the Settings to manually calibrate the time and date

B. Home button:



Click this button to enter the main interface.

C. Brightness button:



Click to adjust screen brightness



Turn on the brightness automatic adjustment, the brightness of the screen of the machine will automatically adjust according to the brightness of the surrounding environment



Turn off automatic brightness adjustment. You can adjust the brightness of the screen by sliding the white progress bar in the middle.

D. Volume button:

Click to adjust the volume

After selecting a different mode, the volume icon will change to the corresponding icon

For example: BT  AUX  Speaker  FM 

E. Screen switch



Click on the screen on the main page to turn off the screen backlight, click anywhere on the screen again to turn on the screen switch, or press the on key on the machine to turn on or off the screen backlight.




Click this button to return to the previous screen

F. DVR




As shown in the picture above, the main page will not display the camera image, you need to click the Dvr button to view the camera image. When a card is inserted, the system automatically enters the video mode, and when recorded, the small red dots in the [Driving Monitoring] button will flash.




	Turn recording sound on or off.
	Lock the video for a few minutes and the data will not be deleted.
	Start recording and click Close recording again.
	View playback video.
	Click here to switch to the settings interface.

G. CarPlay



As shown in the figure above, click the [Apple CarPlay] button to enter the Apple CarPlay and Android Auto selection, click the [Bluetooth Management] option of the interface, and connect to Bluetooth with the mobile phone, you can open the application. When the machine is powered on, it will try to automatically connect to the last connected phone.

(Turn off Wi-Fi button to disconnect. the Apple Carplay option only supports iPhones , Turn off the phone Wi-Fi button to disconnect)



In the setting interface, click split screen display to select full screen, left and right

(Half screen mode)



(Full screen mode)



Note: In the drop-down menu of the mobile phone, you need to click to turn off Bluetooth first, and then click the Turn off WiFi button to disconnect. Just turn off the WiFi button alone, and the car will keep trying to reconnect



H. Andorid Auto




Turn on the Wi-Fi and Bluetooth of the mobile phone first, then select the [Android Auto] option, click the [BT Manage] option of the interface, connect Bluetooth with the phone, you can open the application.

(Turn off Wi-Fi button to disconnect)


After replacing the mobile phone, the connection data of the previous mobile phone will be erased.

Turn on the Wi-Fi and Bluetooth of the mobile phone first, then select the [Android Auto] option, click the [BT Manage] option of the interface, connect Bluetooth with the phone, you can open the application.

(Turn off Wi-Fi button to disconnect)



After replacing the mobile phone, the connection data of the previous mobile phone will be erased.



In the setting interface,  click split screen display to select full screen, left and right


(Half screen mode)




(Full screen mode)




I. Playback



As shown above, click the [Playback] button to enter the video playback interface.



Click the [Delete] button to delete the material.



Click to play or pause the video.



Click or drag the progress bar to fast forward or rewind the video file



Click to switch to the next video



Click lock or unlock the video file, you can select the current file or all files to lock or unlock the file.



Click Delete video file confirm to delete the video file, you can choose to delete the current file or all files.

J. Audio output



As shown in the figure, click the [Audio Output] button to enter the audio output selection interface.

Car audio output: Click to enter, four options (speaker, Carplay/Auto, FM, AUX) can be selected.

1. BT

【 BT 】: Select this mode, and then connect to **【 Apple CarPlay 】** or **【 Android Auto 】** to cast the screen, you can use the phone's Bluetooth to directly connect to the original car's Bluetooth. After the connection is successful, all sounds from the device will be transmitted to the original car speakers via Bluetooth.

After selecting this mode, the volume icon will change to the Bluetooth transmission icon

【 BT 】 Select this mode Click **【 OK 】** to confirm switching from other sound output mode to BT output or switching from BT output mode to other sound output mode when connecting

【 Apple CarPlay 】 or **【 Android Auto 】** Auto will be briefly disconnected before reconnecting, and the volume cannot be adjusted on this device, so the volume must be adjusted on the original car.



Requirements:

1. The car supports Bluetooth.
2. Only iPhone and Android Auto enabled phones are supported Advantages of BT for Carplay feature:

In this mode, the user does not need to set the audio output channel on the mobile phone to the original car Bluetooth device every time after getting in the car. The sound is directly

sent from the mobile phone to the Bluetooth of the original car, and you can enjoy the sound quality of the original car.

BT for Carplay usage steps:


- ① Select **【 BT for carplay/Auto 】** mode in [Audio Channel] on the smart screen.
- ② Connect to Apple Carplay or Android Auto mode with your phone.
- ③ Connect the Bluetooth of the original car with the Bluetooth of the mobile phone.

After completing the above 3 steps, the audio or call data can be played from the original car stereo.

Other instructions:

After completing the above three steps on the Android phone, if the music is still playing from the phone, you need to open the phone status bar and switch the audio output channel to the car Bluetooth playback, as shown in Figure 1 and Figure 2:

Alternatively, in the Bluetooth settings of the phone, locate the Bluetooth device that was previously connected to Android Auto: T93-XXXXXX (not the original car Bluetooth device), click the settings button on the right side of the Bluetooth, and close the [Media Audio] button, as shown in Figures 3 and 4:



2. AUX IN

【 AUX IN 】: After selecting this mode, the AUX output mode will be turned on by default.

Use the AUX sound source cable to connect the smart screen to the original car. After the connection is successful, all the sounds of the device will be transmitted to the original car speakers through the AUX sound source cable for playback.



After selecting this mode, the volume icon will change to the AUX output icon 【 OK 】 , and the volume cannot be adjusted on this device, so the volume must be adjusted on the original car.

3.Loudspeaker

【 loudspeaker 】 Select this mode and click 【 OK 】 button to confirm.



【 Loudspeaker 】 : The sound will be played from the speaker of the smart screen.

4.FM Transmitter

After selecting this mode, click 【 OK 】 button to confirm .the FM transmission mode will be turned on by default. For example, if the device's FM transmit band is tuned to FM 93.3 MHz (any unoccupied channel can be used), the car radio will also tune its receive band to the same FM 93.3 Hz. After the connection is successful, all the sounds of the device will be transmitted to the original car speakers through FM transmission.

After selecting this mode, the volume icon will change to an FM transmission icon 【 FM 】 , and the volume cannot be adjusted on this device, so the volume must be adjusted on the original car.

(Not using the original power cord may result in deterioration of the FM transmission signal or loss of function.)



K. Apple Airplay

Apple AirPlay can transmit videos, audio and pictures from iPhone to car device to play to watch. It is fundamentally different from the Bluetooth wireless.

The transmission carrier is WIFI.

Need iPhone connection to wifi



Select the smart screen in the screen mirror in the iPhone control center


Note: Only support iPhone mobile phones



L. Android Cast

It can realize the mirror projection of the mobile phone and the car machine.

You need to scan the code with your mobile phone to download, install and run the "Dylink" application.



Note: Only supports Android phones

K. Setting



As shown in the figure, click this button to enter the setting interface.



Setting menu details		
Menu function	Menu ICONS	Operation function
Screen Projection		You can choose to display the left, right and full screen projection screen. When switching projection mode, Carplay or Android Auto will be briefly disconnected and then reconnected.
Resolution		In the menu setting interface, users can choose 1440P (2K) or 2160P(4K) video; This Provision This is only for the front camera, not for the back camera
Loop Recording		In the menu setting interface, users can choose the editing time of the movie by themselves, which supports 1 minute, 2 minutes, Three modes in minutes
Microphone		In the menu setting interface, operate this button to turn on or off the recording function
G-sensor		Built-in collision sensor (G-sensor), if a serious collision occurs, the recorder will lock the accident At the same time, the icon at the bottom of the display will automatically change to lock; Be locked in Is saved as a special file that will not be overwritten by the loop. Gravity sensor (G-sensor) supports high, medium, low, close four sensitivity adjustment, according to the real You need to change the Settings by yourself in the Settings menu
Screen Saver		In the menu setting interface, the user can choose the screen sleep function, the machine supports sleep close, 30 seconds, The four modes are 60 seconds and 180 seconds
Rear Video Mirror		In the menu to set the machine interface, the user can choose to open and close the mirror function
Language		In the menu setting interface, users can choose the language according to their needs, support multiple languages: English / 简体中文 / 繁體中文 / 日本語 / 한국어 / русский язык / Français / Español / Polski / العربية

Date/Time		In the menu setting interface, the user can click on the date clock to set, adjust the date and time, and finally Press the "OK" button in the bottom right corner to exit Note: In order to effectively record the date and time of the evidence collection of the driving safety accident, please use this machine before Set the correct time instantly
APP		Scan code download APP to view and download video files See the instructions below.1
Format TF Card		In the menu setting interface, click the operation button, TF card format, there will be a pop-up window, point The "OK" button will format the action
Factory Reset		In the menu Settings interface, click the operation button, a popup will appear, prompting "Restore factory Settings Will delete the usage and revert all Settings to factory status ", click the "OK" button to revert Return factory setup operation
Power On Sound		click (Power On Sound) To enter the settings: you can choose to close or turn it on, When selecting off, the sound effect on the power supply is switched off
About		This item mainly displays firmware version information, including software time and other information, and cannot be set by users.

1.APP

As shown in the figure above, first scan the QR code to download the corresponding APP.
After downloading, open the APP, and follow the APP prompts to connect to the WiFi of the machine. WiFi name: T93-XXXXXX, password as shown on the machine.

(Turn off the mobile phone WiFi key to disconnect)



After the mobile phone has downloaded the APP, turn on the WIFI function of the mobile phone, connect to the hotspot name displayed on the machine side, enter the password 12345678, and wait for the mobile phone and the machine to connect successfully. Open the mobile side APP [Viidure] and click the camera position below. The mobile phone will display the camera preview screen on the machine, and the machine will close any operation and only display the camera preview screen.

2. Wiring and installation of rear pull camera



The installation method of the rear camera is different according to the installation position. Please confirm the installation position before selecting the appropriate installation method.

After confirming the installation position, clean up the oil and dust on the surface of the installation position. If the sticking is not firm, the rear camera may fall off during driving.

It is recommended that the rear camera is installed outside the car for better results. This camera is waterproof, so you don't need to worry about it.


In order to drive safely, please route the wires so as not to hinder driving.

After the vehicle is in reverse gear, the recorder image will automatically switch to the rear camera and display the reverse auxiliary line. After the reverse gear is exited, the device will return to the normal display state.

Although the distance sensing guide line behind the vehicle is displayed in the image of the rear camera, all dangerous obstacles cannot be displayed. Do not just look at the reversing image on the screen and check the rear visually.

Reverse Line Calibration

Park the car in the middle of the parking space, after the vehicle is attached to the reverse gear, when the rear camera preview picture is out of the reverse auxiliary line, manually drag the four corners of the reverse auxiliary line, adjust the position of the reverse car, the reverse auxiliary line, the bottom, and the left and right, so that the reverse auxiliary line and the parking line are flat with the ground



L.Troubleshooting

Item	Problem	Solution
1	Unable to start DVR supports 12~24V car use	1) Check whether the DC head of the cigarette lighter power cord is damaged or aging. 2) Check whether the fuse of the power plug is disconnected or burned.
2	No touch phenomenon	1) Touch is invalid during power-on, wait for normal power-on before operation. 2) Check whether the touch is damaged, do not touch the screen with sharp objects, it is easy to scratch and damage.
3	The rear view camera has no image	1) Buy the manufacturer's matching rear-view camera before it can be used.. 2) Whether the AVIN interface is inserted to the bottom. 3) Check if the camera format matches
4	Carplay cannot connect	1) The first connection takes a little longer. 2) Only iPhone supports Carplay. 3) Check that the WiFi and Bluetooth functions of the mobile phone are normal. 4) Enter Settings-General-Carplay vehicle, delete all records and reconnect. 5) Restart the iPhone and reconnect it.
5	Android Auto cannot connect	1) Only Android phones are supported. 2) Update Auto and related applications on mobile phones to the latest version. 3) Check that the WiFi and Bluetooth functions of the mobile phone are normal. 4) Restart the Android phone and connect it again.

Reminder: Please ensure that there is no obstruction between the mobile phone and the device, and the Wi-Fi / Bluetooth signal communication is smooth, otherwise the product functions cannot be used smoothly.