

TOLSEN MP20^V



87472/87474

Akumulátor 20V

Návod k použití

20V LITHIUM-ION

CB RoHS



ULOŽTE SI TUTO PŘÍRUČKU! Tuto příručku budete potřebovat pro bezpečnostní pokyny, provozní postupy a záruku. Příručku a originál prodejního dokladu uložte na bezpečné suché místo pro budoucí použití.

Důležité bezpečnostní opatření



Varování

Tuto baterii lze použít pouze ve strojích, které jsou součástí systému lithium-iontové platformy TOLSEN MP20V.

Tuto baterii lze používat pouze ve spolupráci s určenou baterií.

Nebezpečí popálení a výbuchu.

Nedodržení těchto pokynů může způsobit přehřátí nebo požár.

1. Baterii uchovávejte mimo dosah dětí.
2. Akumulátor by se měl nabíjet při okolní teplotě mezi 5 a 40 °C (ideálně kolem 20 °C). Po nabití nechte baterii před použitím 15 minut vychladnout.
3. Nabíječka akumulátorů monitoruje teplotu a napětí akumulátoru během nabíjení. NENECHÁVEJTE baterie nabité po delší dobu a NIKDY je neskladujte nabité. Zajistěte, aby byla nabíječka po použití odpojena od elektrické sítě.
4. Pokud se baterie nepoužívají, měly by se skladovat při pokojové teplotě. Neskladujte nářadí a bateriové kazety na místech, kde teplota může dosáhnout nebo překročit 40 °C (ideálně kolem 20 °C) .
5. Zajistěte, aby při skladování nemohlo dojít k náhodnému zkratu kontaktů baterie. Udržujte baterie v čistotě; cizí předměty nebo nečistoty mohou způsobit zkrat. Uchovávejte je mimo dosah jiných jídelních předmětů, například kancelářských sponek, mincí, klíčů, hřebíků a šroubů.
6. Neuchovávejte lithium-iontové akumulátory ve vybitém stavu po dlouhou dobu, protože to může vést k poškození lithium-iontových článků. Pro dlouhodobé skladování skladujte akumulátory ve stavu vysokého nabití odpojené od elektrického nářadí.
7. Baterie se mohou časem poškodit, jednotlivé články baterie mohou selhat a baterie se může zkratovat. Nabíječka nebude nabíjet vadné baterie. Pokud je to možné, použijte jinou baterii, abyste zkontrolovali správnou funkčnost nabíječky, a pokud je indikována vadná baterie, zakupte náhradní baterii.

8. Kapacita baterií se časem snižuje. Po 100 nabíjecích cyklech se doba provozu baterie a maximální krouticí výkon ovladače klouzavě sniží. Tento pokles bude pokračovat, dokud baterie nebude mít po 350 nabíjecích cyklech minimální kapacitu. To je normální a nejedná se o závadu na
9. Neotvírejte, nerozebírejte, nedrťte, nezahřívajte ani nespálujte. Nevyhazujte do ohně nebo podobného zařízení.

specifikace

položka	87472	87474
napětí	20VDC	20VDC
kapacita	2.0Ah	4.0Ah




WARNING

Určená nabíječka baterií TOLSEN položka č.: 87480/87481/87482/87484/87485/87486, která má symbol TOLSEN MP20V.

Před prvním použitím doporučujeme baterii důkladně nabít. Nová baterie dosáhne nejlepšího výkonu po 2 až 3 úplných cyklech nabíjení a

funkce



1. Kontrolky 2. Kontrolní tlačítko. Stisknutím kontrolního tlačítka na akumulátoru se zobrazí zbývající kapacita akumulátoru.

indikační světlo		zbývající kapacita
svítí	Off	
		75% - 100%
		35% - 75%
		5% - 35%

Kontrolky se na několik sekund rozsvítí. POZNÁMKA: V závislosti na podmínkách používání a okolní teplotě se může indikace mírně lišit od skutečné kapacity.

Distributor
Sunnysoft s.r.o.
Kovanecká 2390/1a
190 00 Praha 9
Česká republika
www.sunnysoft.cz



TOLSEN MP20^V

87472/87474 BATTERY PACK

INSTRUCTION MANUAL

20V LITHIUM-ION

CB RoHS



SAVE THIS MANUAL!

You will need this manual for safety instructions, operating procedures and warranty.
Put it and the original sales receipt in a safe dry place for future reference.

IMPORTANT SAFETY INFORMATION



WARNING

This battery can only be used in the machines included in the TOLSEN MP20V lithium-ion power platform system.

This battery can only be used cooperatively with the designated battery charger.

Li-Ion batteries, if incorrectly used, stored or charged will cause a fire, burn and explosion hazard.

Failure to follow these instructions may cause overheating or fire.

1. Keep the battery out of reach of children.
2. The battery should be charged at ambient temperatures between 5 and 40°C (ideally around 20°C) . After charging, allow 15 minutes for the battery to cool before use.
3. The Battery Charger monitors battery temperature and voltage while charging. **DO NOT** leave batteries on charge for extended periods and **NEVER** store batteries on charge. Ensure that the charger is disconnected from the mains supply after use.
4. When not in use batteries should be stored at room temperature. Do not store the tool and battery cartridge in locations where the temperature may reach or exceed 40°C (ideally around 20°C) .
5. Ensure that battery contacts cannot accidentally short in storage. Keep batteries clean; foreign objects or dirt may cause a short. Keep away from other metal objects, for example, paperclips, coins, keys, nails and screws.
6. **DO NOT** store lithium-ion battery packs in a discharged state over a long period as this can damage the lithium-ion cells. For long-term storage, store batteries in a high charge state disconnected from the power tool.
7. Batteries can become faulty over time, individual cells in the battery can fail and the battery could short. The charger will not charge faulty batteries. Use another battery, if possible, to check correct functionality of the charger and purchase a replacement battery if a faulty battery is indicated.

- The capacity of batteries will reduce over time. After 100 charge cycles, the battery's operation time and the maximum torque performance of the driver will slightly reduce. This decline will continue until the battery has minimal capacity after 350 charge cycles. This is normal and not a fault with the battery pack.
- DO NOT** open, disassemble, crush, heat or incinerate. Do not dispose of in fire or similar.

SPECIFICATIONS

Item No.	87472	87474
Voltage	20VDC	20VDC
Capacity	2.0Ah	4.0Ah




WARNING

The designated battery charger TOLSEN item No.:
87480/87481/87482/
87484/87485/87486
which has TOLSEN MP20V symbol.

We recommend to fully charge the battery before use for the first time. A new battery will achieve the best performance after 2 or 3 complete cycles of charge & discharge.

FUNCTIONS





- Indicator lamps
- Check button.

Press the check button on the battery pack to indicate the remaining battery capacity. The indicator lamps light up for a few seconds.

Indicator lamps		Remaining capacity
Lighted	Off	
■ ■ ■		75% to 100%
■ ■ □		35% to 75%
■ □ □		5% to 35%

NOTE: Depending on the conditions of use and the ambient temperature, the indication may differ slightly from the actual capacity.



SUZHOU TOLSEN
TOOLS CO., LTD.

www.tolseentools.com

TOLSEN is a trademark or
registered trademark of TOLSEN
TOOLS. All rights reserved.
MADE IN CHINA



SCAN TO VISIT
PRODUCT LINK
87472



SCAN TO VISIT
PRODUCT LINK
87474