

TOLSEN MP20^V


87485/87486

Incarcator rapid

Instrucțiuni de utilizare

20V LITHIUM-ION

CE RoHS



Distribuitor
Sunnysoft sro
Kovanecka 2390/1a
190 00 Praga 9
Republica Cehă
www.sunnysoft.cz

SALVAȚI ACEST MANUAL!

Veți avea nevoie de acest manual pentru instrucțiuni de siguranță, proceduri de operare și garanție. Păstrați manualul și bonul de vânzare original într-un loc sigur și uscat pentru referințe ulterioare.

INFORMAȚII IMPORTANTE DE SIGURANȚĂ

Avertizare

Acest încărcător poate fi utilizat numai pentru a încărca bateriile care au simbolul TOLSEN MP20V. Există riscul de explozie dacă îl utilizați pentru a încărca alte tipuri de baterii. NU încercați să reîncărcați bateriile nereîncărcabile.

1. Aceasta este o sursă de alimentare de clasă A. Este potrivit doar pentru utilizare în interior.
2. Înainte de utilizare, specificațiile de intrare și de ieșire trebuie verificate pentru a asigura utilizarea corectă.
3. Nu utilizați încărcătorul de baterie dacă polaritatea de ieșire nu se potrivește cu polaritatea sarcinii.
4. Nu încercați să utilizați încărcătorul cu alte baterii decât cele furnizate.
5. Păstrați încărcătorul de baterie curat; Obiectele străine sau murdăria pot provoca un scurtcircuit sau pot bloca orificiile de ventilație. Nerespectarea acestor instrucțiuni poate cauza supraîncălzire sau incendiu. Dacă cablul de alimentare este deteriorat, acesta trebuie înlocuit de către producător, agentul său de service sau o persoană calificată similar pentru a evita un pericol.

SPECIFICAȚII

Model	87485	87486
Input	100-240VAC 50/60Hz Max. 60W	220-240VAC 50/60Hz 110W
Output	21VDC 2.0A	20VDC 4.0A

ATENȚIE: RISC DE ELECTROCUTARE, UTILIZARE NUMAI ÎN LOCAȚII USCATE,
DOAR PENTRU UZ INTERN

INSTRUCȚIUNI DE UTILIZARE

Setări pentru încărcătorul bateriei

1. Dacă o baterie este instalată în încărcător, mai întâi scoateți toate bateriile din încărcător.

2. Introduceți ștecherul de la încărcătorul de baterie într-o priză adecvată.

Notă: LED-ul verde de pe încărcător va fi întotdeauna aprins pentru a indica faptul că încărcătorul este gata să încarce bateria.

Încărcarea bateriei

Observa

Nerespectarea procedurii corecte la încărcarea bateriilor va duce la deteriorarea permanentă a acestora.

1. Introduceți bateria descărcată complet sau parțial în încărcător.

Notă: Asigurați-vă că bateriile și încărcătorul de baterie sunt aliniate corect. Dacă bateria nu se potrivește cu ușurință în încărcător, nu o forțați. În schimb, scoateți bateria, verificați dacă partea superioară a bateriei și fanta încărcătorului sunt curate și nedeteriorate și că nu există contacte îndoite.

2. După ce începe încărcarea, indicatorul luminos roșu se va aprinde.

3. Când bateria este complet încărcată, LED-ul roșu se va stinge și LED-ul verde se va aprinde.

Nota:

1. Bateria trebuie încărcată la o temperatură ambientală între 5 și 40°C (ideal în jur de 20°C). După încărcare, lăsați bateria să se răcească timp de 15 minute înainte de a o folosi.
2. Încărcătorul bateriei monitorizează temperatura și tensiunea bateriei în timpul încărcării. NU lăsați bateriile încărcate pentru perioade lungi de timp și NU depozitați NICIODATĂ bateriile încărcate. Asigurați-vă că încărcătorul este deconectat de la rețea după utilizare.

TOLSEN **MP20^V**


87485/87486

FAST CHARGER

INSTRUCTION MANUAL

20V LITHIUM-ION

CE RoHS



SAVE THIS MANUAL !

You will need this manual for safety instructions, operating procedures and warranty.
Put it and the original sales receipt in a safe dry place for future reference.

IMPORTANT SAFETY INFORMATION

WARNING

This charger can only be used to charge the batteries which has TOLSEN MP20V symbol. If it is used to charge other kinds of batteries, there is a risk of explosion.

DO NOT attempt to recharge non-rechargeable batteries.

1. This is class 2 power supply. It is suitable for indoor use only.
2. Before use, the input and output technical data must be checked to secure correct use.
3. Do not use the Battery Charger in the circumstances that the output polarity does not match the load polarity.
4. Do not attempt to use the charger with any batteries other than those supplied. Keep your battery charger clean; foreign objects or dirt may cause a short or block air vents. Failure to follow these instructions may cause overheating or fire
5. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

SPECIFICATIONS

Item No.	87485	87486
Input	100-240VAC 50/60Hz Max. 60W	220-240VAC 50/60Hz 110W
Output	21VDC 2.0A	20VDC 4.0A

CAUTION: RISK OF ELECTRIC SHOCK, DRY LOCATION USE ONLY , FOR INDOOR USE ONLY

OPERATING INSTRUCTIONS

Setting up the battery charger

1. If there is battery fitted, remove any battery from battery charger first.
2. Insert the Battery Charger mains plug into a suitable mains socket.

Note: The Green LED on the Charger will always bright to indicate that the charger is ready to charge the battery.

Charging the battery

WARNING

Failure to follow the correct procedure when charging batteries will result in permanent damage.

1. Slide a fully or partially discharged Battery on to the Battery Charger.

Note: Make sure the Battery and Battery Charger are lined up correctly. If the Battery does not slide on to the Battery Charger easily, don't force it. Instead, remove the Battery, check the top of Battery and the Battery Charger slot are clean and undamaged and that the contacts are not bent.

2. Once charging commences, the Red LED will on.
3. When the Battery is fully charged, the Red LED will off and Green LED will on.

Note:

1. The battery should be charged at ambient temperatures between 5 and 40°C (ideally around 20°C) , After charging, allow 15 minutes for the battery to cool before use.
2. The Battery Charger monitors battery temperature and voltage while charging. **DO NOT** leave batteries on charge for extended periods and **NEVER** store batteries on charge. Ensure that the charger is disconnected from the mains supply after use.

CE DECLARATION OF CONFORMITY

WE
SUZHOU TOLSEN TOOLS CO.,LTD.
198 HUASHAN ROAD, ZHANGJIAGANG,
JIANGSU, CHINA

Declare that the product
87485/87486
FAST CHARGER

Complies with the essential health and safety requirements of the following Directices:
council directive 2006/42/EC



Standards and technical specifications referred to:
EN 60335-2-29:2004/A11:2018
EN 60335-1:2012/A2:2019
EN 62233:2008

Authorised Signatory and technical file holder

Signed for and on behalf of:
SUZHOU TOLSEN TOOLS CO.,LTD.
198 HUASHAN ROAD, ZHANGJIAGANG,
JIANGSU, CHINA

WANG QING
Group Quality Director
on:07/02/2022





SUZHOU TOLSEN
TOOLS CO.,LTD.

www.tolsentools.com

TOLSEN is a trademark or
registered trademark of TOLSEN
TOOLS. All rights reserved.
MADE IN CHINA



SCAN TO VISIT
PRODUCT LINK
87485



SCAN TO VISIT
PRODUCT LINK
87486