


# ThermoPro

## Indoor Humidity And Temperature Monitor Instruction Manual

Model No.: TP-50



English..... 2      Français..... 13

V20191105 EN FR

## General Warning



### **DANGER!**

This device contains electronic components which operate via a power source (power supply and/or batteries). Do not let children use the device while unattended. Only use the device as described in the manual, otherwise you run the risk of an electric shock.

Children should only use the device under adult supervision. Keep packaging material, like plastic bags and rubber bands, out of the reach of children, as they pose a choking hazard.

Keep batteries out of the reach of children. Make sure you insert the batteries correctly. Empty or damaged batteries could cause burns if they come

into contact with the skin. If necessary, wear adequate gloves for protection.



### **DANGER!**

Do not expose the device to high temperatures. Use only the recommended batteries. Do not shortcircuit the device or batteries, or throw them into a fire. Excessive heat or improper handling could trigger a short-circuit, a fire or an explosion!



### **NOTE!**

Do not disassemble the device. In the event of a defect, please contact your dealer. The dealer will contact the Service Centre and can send the device in to be repaired, if necessary.


Use only the recommended batteries. Always replace weak or empty batteries with a new,

complete set of batteries at full capacity. Do not use batteries from different brands or with different capacities. The batteries should be removed from the unit if it has not been used for a long time.

### Notes on cleaning

Separate the device from the power supply or remove the batteries before cleaning.

Only use a dry cloth to clean the exterior of the device. Do not use any cleaning fluid to avoid damaging the electronics.



1. Display: Displays the current humidity and temperature, and record maximum and minimum humidity/temperature.
2. °C/°F/Clear Button: Press once to change the temperature display to either °C or °F. Press and hold for 2 seconds to clear the record maximum and minimum humidity/temperature readings.
3. Battery Compartment: Holds one 1 AAA battery

to power the unit.

4. Comfort Level: 3 icons: DRY, COMFORT, WET.

If humidity is below 30%: Dry.

If humidity is between 30% to 60% AND temperature is between 68°F ~ 79°F(20°C ~26°C): Comfort.

If humidity is above 60%: Wet.

If none of these conditions are met: No Icon.

5. Totally wireless tabletop and magnetmountable design.

### Before first use

1. Insert or Replace Battery: Insert one AAA battery with correct polarity (+) and (-) as indicated.
2. Do not immerse product in water.

3. The humidity and temperature monitor is now ready to use.

### Care of your Humidity/Temperature monitor

- Do not leave exposed to extreme high or low temperatures since this may cause damage to electronic parts and plastics.
- Remove battery if planning to store for more than four months.

### Specifications

1. Temperature range: -58°F ~ 158°F(-50°C ~ 70°C).
2. Humidity range: 10% ~ 99%.
3. Comfort display: DRY, COMFORT, WET.

4. Temperature display unit: °C °F selectable.
5. Temperature Resolution: 0.1 °C/°F.
6. Humidity Resolution: 1%.
7. Refresh rate: 10 seconds.
8. Power supply: 1 X AAA 1.5V.

## Declaration of Conformity

Hereby, the manufacturer declares that this product complies with the basic requirements and applicable regulations of the EMC Directive 2014/30/EU. The complete declaration of conformity can be found at:  
<https://itronicsmall.com/eu-declaration-of-conformity/>

## Disposal



### Meaning of the “Dustbin” Symbol

- Protect our environment: do not dispose of electrical equipment in the domestic waste.
- Please return any electrical equipment that you will no longer use to the collection points provided for their disposal.
- This helps avoid the potential effects of incorrect disposal on the environment and human health.
- This will contribute to the recycling and other forms of reutilisation of electrical and electronic equipment.

- Information concerning where the equipment can be disposed of can be obtained from your local authority.



**CAUTION:** Batteries/rechargeable batteries must not be disposed of with household waste!

- The batteries must be removed from the appliance.
- Take spent batteries to the appropriate collection point or to a dealer.
- Your town or local authority can provide information about public collection points.

This symbol can be found on batteries/rechargeable batteries which contain hazardous:



- Pb = contains lead
- Cd = contains cadmium
- Hg = contains mercury
- Li = contains lithium

### Limited one-year Warranty

ThermoPro warrants this product to be free of defects in parts, materials and workmanship for a period of one year, from date of purchase.

Should any repairs or servicing under this warranty be required, contact Customer Service by phone or email for instructions on how to pack and ship the product to ThermoPro.